# Meggitt Fuelling Products Avery-Hardoll Whittaker Controls

# 1.5 in. Sampling, vent or drain valve GBMY3806M2

## IOM with spare parts

Publication ref TP0040 Issue 3 November 2000

> Avery-Hardoll Holland Way Blandford Forum Dorset DT11 7BJ

Tel: +44 (0) 1258 486600 Fax: +44 (0) 1258 486601

www.meggittfuelling.com


Whittaker Controls 12838 Saticoy St North Hollywood California 91605-3505 USA

Tel: +1 818 765 8160 Fax: +1 818 759 2194

> www.wkr.com www.meggitt.com

MEGGITT smart engineering for extreme environments

The information contained herein is the property of Avery Hardoll a division of Meggitt (UK) Ltd. No part may be reproduced or used except as authorised by contract or other written permission. The Company reserves the right to alter without notice the specification, design or conditions of supply of any product or service.




### 11/2 INCH SAMPLING VALVE (INTERNALS) S/ASSY

## GBMY3806M2-1 1½ INCH UNIT WITH SINGLE BLEED VALVE GBMY3806M2-2 1½ INCH UNIT WITH DOUBLE BLEED VALVE

<u>ITEM</u>	PART NO.	<u>DESCRIPTION</u>	<u>QTY</u>
1	CCMY4VN	1½ inch Blanking Cap Assy.	1
2	CCMY8156-1	11/2 inch St. St. Tank Unit (Extended) + Drilled	1
* 3	ZO32E220139A	'O' Ring (Viton)	1
4	CCSZ8171	Valve	1
5	ZT4001MF416A	Tension Pin	1
6	CCSZ8172	Valve Stem	2
7	CCSZ223	Spring	1
8	ZT4012M0316A	Groove Pin	1
9	CCSZ8173	Valve Guide	1
10	ZS3226D2036A	Bolt $^{5}/_{8}$ inch – 11 UNC x $2^{1/_{4}}$ inches long	4
11	ZW2201G20A	Washer <sup>5</sup> / <sub>8</sub> inch Plain	16
12	ZW8207G20A	Spring Washer ½ inch single coil	16
13	ZN2201D20A	Nut <sup>5</sup> / <sub>8</sub> inch -11 UNC	16
14	ZMMZ0135-9	1/4 inch Dowty Sealing Washer	1
15	ZMMZ0320-04	Pressure relief / Bleed valve 200psi, UNF	1
16	GBFZ3772	Gasket	3
17	ZAMZ0302-9	Firesafe Ball Valve Assembly complete	2
18	ZASZ0028-29	Stud <sup>5</sup> / <sub>8</sub> inch - 11 UNC x 3 <sup>3</sup> / <sub>8</sub> inch long	4
19	ZASZ0028-17	Stud <sup>5</sup> / <sub>8</sub> inch - 11 UNC x 2 <sup>5</sup> / <sub>8</sub> inch long	4
20	GBSZ3763 GBSZ3763-1	Base flange Base flange with 1½ inch pipe	1 1
21	ZS4005M05008A	Screw pan head M5	1
22	ZW4006M05A	Washer M5 Shakeproof	1
23	ZACZ0017-13	Plug ¼ inch BSPT (GBMY3806M2-1 only)	1
24	ZMMZ0320-05	Pressure relief / Bleed valve 200psi, BSPT (GBMY3806M2-2 only)	1

<sup>\* =</sup> Suggested spares.



- 1 Ensure that the block valve (1) is fully closed.
- 2 Vent tank unit (2) via the pressure relief/bleed valve (3).
- 3 Remove the blanking cap (4).
- 4 Connect 1<sup>1</sup>/<sub>2</sub> inch hose unit to the tank unit (2).
- 5 Open the block valve (1)
- 6 Take the required sample.
- 7 Fully close the block valve.
- 8 Disconnect the hose unit.
- 9 Replace the blanking cap.

10 Avery-Hardoll undertake to supply this unit only on the basis of the customers acceptance of the above operating procedure. Such procedure is to be displayed in the pit and to be fully visible to the operator.



#### Hydrostatic pressure testing procedure

- 1 Remove 1<sup>1</sup>/<sub>2</sub> inch tank unit (2)
- 2 Remove pressure relief valve (5) if fitted and plug the hole with a 1/4 in. BSP taper plug part no. ZACZ0017-13 or similar.
- 3 With the block valve (1) closed, hydrostatic pressure test at 300 lbs/in<sup>2</sup> for one minute without leakage.
- 4 Replace the tank unit, fitting <sup>1</sup>/<sub>4</sub> inch UNF plug and Dowty sealing washer in place of the pressure relief/bleed valve (3).
- 5 With the block valve open, hydrostatic pressure test at 300 lbs/in2 for one minute without leakage
- 6 Release the pressure to atmosphere, close the block valve and replace the pressure relief/bleed valve.
- 7 With block valve open, gradually increase pressure until the pressure relief/bleed valve operates. This should occur at  $200lbs/in^2 \pm 5lbs/in^2$ .
- 8 Reduce pressure to 180lbs/in<sup>2</sup> and close the block valve. In this condition, carefully open the pressure relief/bleed valve by pulling its spindle outwards thus releasing the pressure in the tank unit to atmosphere. Couple and uncouple the <sup>1</sup>/<sub>2</sub> in hose unit.
- 9 Refit the pressure relief valve (5). Close the block valve (1) and gradually increase the pressure until the pressure relief valve (5) operates. This should occur at 200lb/in<sup>2</sup> ± 5lb/in<sup>2</sup>.

#### **CAUTION**

Ensure that the block valve (1) is fully closed before operating the pressure relief/bleed valve (3). THE BALL VALVE MUST BE KEPT FULLY CLOSED AT ALL TIMES, EXCEPT DURING SAMPLING OPERATIONS.